Warranty

Xtracycle LockPockets are guaranteed to be free from manufacturing defects for one (1) year from the original date of purchase.

Defective products will be repaired or replaced at Xtracycle's discretion. To determine if a warranty claim is valid you may be required to return the product to Xtracycle for inspection. Xtracycle is not responsible for removal, installation or shipping costs. This warranty applies only to the original buyer and is not transferable.

This warranty does not cover damage from use of this product outside of its intended range or that resulting from modification or neglect. It also does not cover wear and tear resulting from the normal use of the product.

Double your warranty to two years! Register your Xtracycle LockPocket within 14 days of purchase to extend your warranty to two years.

http://www.xtracycle.com/register

Notices:

Warning: Do not use LockPocket on V-Racks without wheel protection like WheelSkirts or Xtracycle bags.

Our mission:

To empower people with transformational tools that move the body and spirit.

www.xtracycle.com





XTRACYCLE

LockPocket[™] Manual

The Xtracycle LockPocket is a convenient place to put your bike lock, keys, patch kit, wallet, phone, kid snacks or anything else you want to access easily. Simply unbuckle to take it with you.



Compatibility:

You can attach the LockPocket to your front handlebars, the V-Racks or the Hooptie.

www.xtracycle.com

Easy Install:

Attach Buckles



Wrap the hook-and-loop straps around racks or tubing and secure. Clip in side-release buckles.

Note: Position Away From Brakes



Avoid positioning the LockPocket over the brakes. Longer locks may cause damage.

Features:





- Two compartments for storage
- Internal clip for keys
- Slot for hanging lock

Versatility:

Some Places to Put the LockPocket





- Can be installed on many styles of handlebars.
- Can also be installed on a Hooptie

DIY MOD Project: Modifying the LockPocket to hook into the inner loops on the CargoBay

Step 1:



Take off the hook-and-loop strap. Create a c-clip by cutting a 1/8" gap on the back end of the female buckle.

Step 3:



Clip in LockPocket

Step 2:



Feed the newly modified clips around the webbing loops at the top of the CargoBay

Voila!

