

Warranty

Xtracycle WheelSkirts are guaranteed to be free from manufacturing defects for one (1) year from the original date of purchase.

Defective products will be repaired or replaced at Xtracycle's discretion. To determine if a warranty claim is valid you may be required to return the product to Xtracycle for inspection. Xtracycle is not responsible for removal, installation or shipping costs. This warranty applies only to the original buyer and is not transferable.

This warranty does not cover damage from use of this product outside of its intended range or that resulting from modification or neglect. It also does not cover wear and tear resulting from the normal use of the product.

Double your warranty to two years!
Register your Xtracycle WheelSkirts within 14 days
of purchase to extend your warranty to two years.

<http://www.xtracycle.com/register>

Notices:

Warning: Always use wheel protection like WheelSkirts or Xtracycle bags when riding with passengers or cargo.

Notice: If using WheelSkirts, they should be firmly tensioned across the V-Racks at all times.

Note: This assembly is possible with the FlightDeck installed, however, it is much easier if you attach the top hook-and-loop straps before installing the FlightDeck.

Our mission:

To empower people with
transformational tools that
move the body and spirit.

www.xtracycle.com

WheelSkirts
SKU: 3BG1200



REV1C

XTRACYCLE

EdgeRunner WheelSkirts Manual

Bomber Barrier Protects Passenger Feet and Cargo



What's Included:

- 1 Left WheelSkirt
- 1 Right WheelSkirt

Compatibility: The EdgeRunner WheelSkirts work with EdgeRunners with LT2 V-Racks. CargoBays or CarryAlls can be installed on top of WheelSkirts.

www.xtracycle.com

STEP 1:

Match WheelSkirt to V-Rack



The angle of the WheelSkirts will match the angle of the V-Rack with the Xtracycle logo facing out.

STEP 2:

Hang WheelSkirt



Use hook-and-loop straps to hang the WheelSkirt across the top of the V-Racks.

STEP 3:

Center the WheelSkirt



Wrap hook-and-loop straps around vertical uprights (front and rear) of the V-Racks. Pull straps tight before securing.

STEP 4:

Attach Straps to Chainstay



Attach hook-and-loop straps to the horizontal "chainstay" tube at the bottom of the EdgeRunner frame. Pull each strap tight before securing. Be careful to not wrap webbing around housing or cable.

STEP 5:

Tension WheelSkirt



Go back and tighten all straps until WheelSkirt is firmly tensioned around the rack and bottom of frame. Pressing with your hand toward the wheel with ten pounds force you should not be able to cause the WheelSkirt to touch the tire.

STEP 6:

Install the other WheelSkirt



Repeat steps 1-5 on the opposite side of bike.