

STAND TASTIC

Wall Mount Kit Assembly

1.



Attach vertical frames to wall using lag bolts. Make sure to attach to studs in wall. Other method of attaching may be needed depending on type of wall. Make sure vertical frames are secure before attaching tier kits

2.



Attach tier brackets as shown above.

3.



Tighten allen wrench to tighten allen set screw to secure bracket in position.



Place fast pins in position as shown above. Top pin will be always as shown. Bottom pin can be used in alternate positions to adjust angle. For the closest to 90 degree place pin in bracket as shown below and allow tier arm to rest on pin.



1325 Meridian St.
Anderson, IN 46016
765-643-3802