



1. This product must be installed by licensed plumber. Unlicensed installation will void warranty.
2. Ensure all o-rings are lubricated with silicone based lubricant.
3. Fit Bottle Trap to appropriate 40mm Waste.
4. Adjust bottle trap height to in-wall outlet pipe and ensure there is a adequate fall in the outlet pipe when installed.
5. Measure and trim outlet pipe, ensuring there is adequate allowance for pipe and rubber seal to fit into connector.
6. Firmly tighten all joints. Do not over-tighten, Test for leaks.