

How to use The Strike Alpha Adaptor for System 9 base Plate



This adaptor allows a user to connect a Strike Alpha cradle to a Bury System 9 base plate. The existing power and antenna connections to the base plate do not have to be altered in any way. The adaptor makes Strike Alpha Cradles 'plug and play' with System 9 base plates.

1. The 3 components in the picture below are the Strike Alpha Adaptor, an Alpha iPhone 6 Car Cradle and a Bury System 9 base plate with a System 9 Cradle attached to it.



2. Attach the adaptor to the Strike Alpha Cradle.



3. Screw the FME antenna connectors together.



4. Plug the USB cable from the Alpha Cradle into the USB port of the adaptor.



5. Use the provided prongs on the adaptor to tidy up excess cables.



6. Remove the Bury System 9 cradle.



7. Attach the Adaptor and Strike Alpha Cradle.



CONGRATULATIONS!

You have a phone specific cradle on your System 9 base plate.