



APOC NOTES:

1. DO NOT "TENT" OVER FASTENER HEADS WITH TAPE . PROVIDE PRE-CUT OPENINGS TO ELIMINATE "TENTING" OR PLACE TAPE NEXT TO FASTENER LINE.



"R" PANEL VERTICAL SEAM

ME-1
 ACRYLIC, TAPE + 264
 NOT DRAWN TO SCALE