



\* SCREWS  
WILL BE  
SCREWED INTO  
THE UPRIGHTS  
\* UNSCREW  
THEN RE-SCREW  
ON TO BASE

\* 2 SCREWS  
ONLY  
NEEDED

- LEVELLER (4)  
FOR EACH CORNER