



ASSEMBLY INSTRUCTIONS

1. Assemble end frames and connectors with screws and washers.
(NOTE : Adjustment holes must face inward)
2. Assemble end frames and stretcher with screws and washers.
3. Insert straight arms (Slant ball arms) into end frames.
(NOTE : Single push button must fit adjustment hole)

K-10 : 4 ARM RACK STRAIGHT ARM 18"

K-15 : 4 ARM RACK SLANT ARM-8 BALL-16"