

# WeatherTech®

## BumpFrame™

### License Plate Frame Mounting Instructions

*TOOLS NEEDED • #2 Phillips Head Screwdriver • 7/16" Wrench*

1. Remove and re-use your original mounting hardware to install your WeatherTech® BumpFrame™ license plate frame.
2. Lay the WeatherTech® BumpFrame™ face down on a soft or non-abrasive surface.
3. Position the license plate face down into the recessed area on the back of your BumpFrame™, noting that the BumpFrame™ has the WeatherTech® logo along the bottom for proper positioning.
4. Carefully position your BumpFrame™ and license plate assembly into place, and reinstall using your original mounting screws. Securely fasten BEING CAREFUL NOT TO OVER-TIGHTEN.

#### CONTENTS:

- BumpFrame™
- *Hardware Not Included*

#### CARE INSTRUCTIONS:

- Clean with soapy water or window cleaner
- Do not use abrasive pads, harsh detergents or degreasers on the BumpFrame™

#### HELP!

If you have questions regarding installation of this or any other WeatherTech® product, please call our customer service department at (630) 769-1500, Mon-Thur: 7am-11pm, Fri: 7am-10pm, Sat-Sun: 8am-8pm (CST). We want to help you get the most out of your new WeatherTech® product.

---

PLEASE CHECK STATE AND LOCAL LAWS PRIOR TO USE.

