

WeatherTech®

ClearFrame™

License Plate Frame Mounting Instructions

TOOLS NEEDED • #2 Phillips Head Screwdriver • 7/16" Wrench

1. Remove the Click and Stay™ screw caps from the mounting holes in the WeatherTech® ClearFrame™ by pushing them out from the back side.
2. Lay the WeatherTech® ClearFrame™ face down on a soft or non-abrasive surface.
3. Position the license plate face down into the protective gasket that is molded into the edge of your ClearFrame™, noting that the ClearFrame™ gasket is marked "BOTTOM" for proper positioning. Make certain that you have a proper fit and seal between the license plate and the ClearFrame™.
4. Select the four mounting screws that are most appropriate for your vehicle (If your mounting location only uses 2 holes, then see step 4A FIRST). Carefully position your ClearFrame™ license plate assembly into place on your vehicle and using a #2 Phillips Head Screwdriver, securely fasten with the screws you have chosen, BEING CAREFUL NOT TO OVER-TIGHTEN.

(4A) If the mounting location on your vehicle only uses two screws, then first select machine screws and matching nuts from the hardware pack. Install these two screws through the ClearFrame™ license plate assembly in the holes that DO NOT go to the mounting holes on the vehicle. Using a #2 Phillips Head screwdriver and a wrench, tighten the two nuts onto the end of each screw, locking the assembly together, BEING CAREFUL NOT TO OVER-TIGHTEN.
- 5) Finally, position the Click and Stay™ screw caps over each screw on your ClearFrame™ with the drain hole on the bottom and push firmly to snap each one into place.

HELP!

If you have questions regarding installation of this or any other WeatherTech® product, please call our customer service department at (630) 769-1500, Monday through Friday, 9 a.m. to 5 p.m. Central Time. We want to help you get the most out of your new WeatherTech® product.

PLEASE CHECK STATE AND LOCAL LAWS PRIOR TO USE.



CONTENTS:

- ClearFrame™ License Plate Cover
- Stainless Steel Universal Fastener Kit
- Click and Stay™ Screw Caps

CARE INSTRUCTIONS:

- Clean with soapy water or window cleaner
- Do not use abrasive pads, harsh detergents or degreasers on the ClearFrame™

High Quality Stainless Steel Universal Fastener Kit*



* Some vehicle models may require re-use of existing fasteners

For joining cover & plate without mounting holes

FITS THESE MODELS AND MORE:

Acura, AM General, Audi, BMW, Buick, Cadillac, Chevrolet, Chrysler, GMC, Daewoo, Dodge (except Viper), Ferrari, Ford, Honda, Hummer, Hyundai, Isuzu, Infiniti, Jaguar, Jeep, Kia, Land Rover, Lexus, Lincoln, Mazda, Mercedes-Benz®, Mitsubishi, Nissan, Oldsmobile, Pontiac, Porsche®, Range Rover, Saab, Saturn, Scion, Subaru, Suzuki, Toyota, Volkswagen, Volvo