



Rinse Wall Shower Assembly Instructions

Congratulations on your purchase of a Rinse Outdoor Shower!
Your shower is designed to be easy to assemble, easy to operate, and easy to maintain.



1. Place bottom edge of mounting board 42" from ground or floor.



2. Check that mounting board is level and perpendicular to ground or floor.



3. Screw mounting board to surface using 3" screws.



4. Fit shower mount over mounting board as shown.



5. Screw shower mount to mounting board on both sides using 2" screws.



6. Twist rain shower head onto shower stem as shown.



7. Attach hand wand hose to shower fixture as shown.

Your Wall Shower is now ready to hook up to a garden hose. Connect a garden hose to the fitting on the rear of the shower and turn on the water. If adding hot water via a garden hose simply remove the cap on the other rear fitting and attach the included swivel fitting. If having a plumber connect hot and cold directly to the shower simply remove the hose fittings and connect directly to the shower.



info@rinseshowers.com