

Before Getting Started:

You will need:

- Campania's Cast Stone Touch Up Stain
- Cast Stone Sealer (for applicable stains)
- Large Sponges
- Spray Bottle for Large Scale Applications
- Soft Counter Brush for Large Scale Applications

Shake well before using.

Clean items before staining.

Always dampen the area where stain is to be applied.

- Use a damp sponge or mist setting on a hose nozzle
- Do not saturate any items that are being stained

For large scale applications

- Use a drop cloth or tarp for easy clean up.
- Only apply stain to a small number of pieces at a time. All stains must be applied and left to set for 5 minutes before the excess stain can be removed with a damp sponge or cloth.
- Work in a shaded area to allow the stain to set evenly. Direct sunlight may cause the stain to dry unevenly.



Single Color Stains (AS, EM, GS, and VE):

1. Apply a thin coat of stain with a clean, damp sponge or spray bottle and brush.
2. Let the stain set for approximately 5 minutes.
3. Wipe off the excess stain with a clean damp sponge or cloth.
4. Allow the stain to finish drying completely.
5. Repeat Steps 1-4 as needed to achieve desired color.





Single Color Stains with Sealer (BR and TR):

1. Apply a thin coat of stain with a clean, damp sponge or spray bottle and brush.
2. Let the stain set for approximately 5 minutes.
3. Wipe off the excess stain with a clean, damp sponge or cloth.
4. Allow the stain to dry completely.
5. Repeat Steps 1-4 as needed to achieve desired color.
6. Lightly apply the sealer with a dry sponge or cloth.
7. Let the sealer dry completely.



Multiple Application Stains with Sealer



Aged Limestone Finish (AL)

For touching up a small chip area, you only need to dab on and blend "AL2" and/or "AL3".

1. Apply "AL1" with a clean, damp sponge or spray bottle and brush.
2. Allow the stain to dry completely.
3. Wet the piece thoroughly and apply a light coat or sprinkling of "AL2".
4. Lightly apply "AL3" with a clean, damp sponge or spray bottle and brush.
5. Allow the stain to dry completely.
6. Lightly apply the sealer with a dry sponge or cloth.
7. Let the sealer dry completely.



Copper Bronze Finish (CB)

For touching up a small chip area, you only need to dab on and blend "CB2" and/or "CB3".

1. Apply "CB1" with a clean, damp sponge or spray bottle and brush.
2. Allow the stain to dry completely.
3. Wet the piece thoroughly and apply a light coat or sprinkling of "CB2".
4. Lightly apply "CB3" with a clean, damp sponge or spray bottle and brush.
5. Allow the stain to dry completely.
6. Lightly apply the sealer with a dry sponge or cloth.
7. Let the sealer dry completely.



French Limestone Finish (FL)

For touching up a small chip area, you only need to dab on and blend "FL2".

1. Apply "AL1" with a clean, damp sponge or spray bottle and brush.
2. Allow the stain to dry completely.
3. Apply "FL2" with a clean, damp sponge or spray bottle and brush.
4. Wet the piece thoroughly and apply a light coat or sprinkling of "FL3".
5. Allow the stain to dry completely.
6. Lightly apply the sealer with a dry sponge or cloth.
7. Let the sealer dry completely.



Ferro Rustico Nuovo Finish (FN)

For touching up a small chip area, you only need to dab on and blend "FN2" and/or "AL2".

1. Apply 2 coats of "FN1" with a clean, damp sponge or spray bottle and brush.
 - a. Allow the stain to dry between coats.
2. Allow the stain to dry completely.
3. Wet the piece thoroughly and apply 1 coat of "FN2" with a clean, damp sponge or spray bottle and brush.
4. Apply a light coat or sprinkling of "AL2".
5. Allow the stain to dry completely.
6. Lightly apply the sealer with a dry sponge or cloth.
7. Let the sealer dry completely.



Lead Antique Finish (LA)

For touching up a small chip area, you only need to dab on and blend "LA1".

1. Apply 2 coats of "LA1" with a clean, damp sponge or spray bottle and brush.
 - a. Allow the stain to dry between coats.
2. Allow the stain to dry completely.
3. Wet the piece thoroughly and apply a light coat or sprinkling of "CB1".
4. Allow the stain to dry completely.
5. Lightly apply the sealer with a dry sponge or cloth.
6. Let the sealer dry completely.



Nero Nuovo Finish (NN)

1. Apply 3 coats of "NN" with a clean, damp sponge or spray bottle and brush.
 - a. Allow the stain to dry between coats.
2. Allow the stain to dry completely.
3. Lightly apply the sealer with a dry sponge or cloth.
4. Let the sealer dry completely.



Pietra Nuova Finish (PN)

For touching up a small chip area, you only need to dab on and blend "PN2".

1. Apply 2 coats of "PN1" with a clean, damp sponge or spray bottle and brush.
 - a. Allow the stain to dry between coats.
2. Wet the piece thoroughly and apply 1 coat of "PN2" with a clean, damp sponge or spray bottle and brush.
3. Allow the stain to dry completely.
4. Lightly apply the sealer with a dry sponge or cloth.
5. Let the sealer dry completely.