



Polaris RZR Pro-XP Rear Bumper Installation

Thank you for purchasing our product. Below you will find the steps necessary to properly install your new B&M Fabrications rear bumper.

1. Attach the upper strut mounts to the machine as pictured using the 3/8" x 2 3/4" Bolts/washers/Flanged nuts. Do not fully tighten.
2. Using the 3/8" x 1" bolts mount the lower section of the bumper to the machine. Do not fully tighten.
3. Connect the upper struts to the top of the rear bumper as pictured using the remaining 3/8" x 3/4" flanged bolts.
4. Center the bumper onto your machine and tighten all bolts.



www.bmfabrications.com 6122029245