

Carefully repack your GarageSkins system!



PLEASE FOLLOW THESE STEPS TO CAREFULLY RE-PACK YOUR GARAGESKINS SYSTEM

1. Make sure 1" white Styrofoam is correctly placed in the bottom and sides of the box.

2. Use a sheet of bubble wrap and place it in the bottom of the box.

3. Carefully place one panel into the box, tilting it in to protect the corners of the panel. Gently lower panel into the box until flat.

4. Place a sheet of bubble wrap on top of the panel to protect the wood surface.

5. Continue carefully tilting panels into the box separated by a sheet of bubble wrap.

6. Once the last panel is in, place a sheet of bubble wrap over the top.

7. Use a small sheet of bubble wrap to protect the side of the top panel from the hardware box.

8. Place the hardware box to the side of the top panel.

9. Place the remaining large sheet of 1" thick Styrofoam over the top.

10. Place the (2) honeycomb protection panels over the Styrofoam.

Close and tape the box, running packing tape around the entire box in at least 3 different places. If you have multiple boxes, there should be an equal number of panels in each box.

