

# iCBL

This DIY will help guide you install *iCBL's* Carbon Fiber Rear Bumper Splitters.

**Step 1:** First off, you will need to clean & prep your rear bumper for installation. Use a clean microfiber towel, and alcohol (or any detailer) to wipe down the underside of the rear bumper. A clean, dry surface is required in order for parts to stick properly.



**Step 2:** For this next step, DO NOT peel and remove the top layer of the double sided tape just yet! You will need to hold your splitter and adjust it by moving it around till you achieve the way you want it to look. (Please refer to the image provided below for reference)



**Step 3:** Now that you have aligned the splitters, you can go ahead and start removing the top layer to expose the double sided tape.

**Step 4:** After peeling the top layer of the double sided tape, apply the splitters to your underside of the rear bumper. You can also choose to use the Self tapping screws provided or just mount it with the double sided tape. (Tested to hold up to 30LBS)

**Step 5:** Repeat steps 1-4 for the other side of your vehicle. Once finished, step back and enjoy the new look of your Rear Bumper Splitters!

