1:32 Land Rover Britains Defender Detail Kit

1x Snorkel, 1, Winch, 1x A-Bar, 6x Spot Lights, 2x Front Grill Lights, 2x Rear Work Lights, 1x Checker plate Sheet

This is a rough guide to using the kit. Care should be taken at each stage to make sure the model is going together correctly and any alterations that are not in the instructions should be carried out.

Paint: Components can be painted at any time in the build, it is a case of what suits the builder. Modelling paints or automotive spray paints can be used.

Glue: Recommended glue is contact adhesive or super glue. We used Gorilla Super Glue (Blue Lid)

1 Separate the chassis. The parts here have been brush painted with a matt black Tamiya XF paint. Any modelling paint can be used. They are glued to the model using Gorilla Super Glue and Deluxe Materials Glue n Glaze.

Snorkel. Painted and glued over the air vent on the original casting

Checker Plate. Cut to suit the bonnet contours or the side trims. Then paint and glue to the bonnet/sides.

Spots. Painted black then silver in the centres, glued equally spaced to the roof



A-Bar. Big spots glued to top of bar and then painted. Silver in lamp painted first then black lightly brushed over the top.

Wheels. Paint the wheels as desired then push fit to axles and slide through the original axle holes.

Winch. Painted black and silver then glued to the front of the bumper over the original number plate.

