

# Lil' and Big Chingon blind setup 5ft. Tower

## Specifications w/ minimum allowable room\*

5x5 w/5' tower – 94"x68"x98" tall\*

Weight - 675lbs.\*

7x7 w/5' tower – 110"x86"x98" tall\*

Weight - 1025lbs.\*

Required tools for install: Ladder, Ratchet, 14mm socket, 19mm socket, 14mm wrench, shears (for strap cutting)

## **Blinds with 5' legs**

Remove legs from banding where attached to porch and place aside.

Remove the provided bolt packet and handrail extensions from inside the blind and place aside.

Using the intergraded forklift slots, lift the blind enough to place leg stud bolts (larger 19mm bolts in package) into the nuts that are welded onto the leg studs.

Lifting to appropriate height, start inserting the legs making sure the foot pads are facing out.

Tighten the bolts just enough to hold legs secure until the blind is in position.

Once all legs are secure, lower blind into position and kick the legs out to make sure the blind is level, and all legs are all making contact with the ground. If the ground is not level, you can loosen the bolts the allow the leg to drop a bit and help level the blind out.

Once the blind is level tighten the bolts on the leg studs to secure.

## **The Staircase**

Loosening and leaving the bolts on the bottom of the staircase, remove the bolts on the top rail and carefully hinge the staircase down into position.

Insert the handrail extensions into the top of the rail and using the supplied 14mm bolts and washers, loosely attach to the top holes on the blind porch.

Once the staircase is in position and all bolts are inserted, you can now tighten all remaining bolts.

## **Securing blind in position**

In the event you are wanting to secure your blind in position, we have provided holes in the footpads for stakes (not provided) and there is a central location on the bottom of the blind frame for securing a cable tie-down system (not supplied).

\*\*All weights and measurements are approximate

# Lil' and Big Chingon setup 8ft. Tower

## Specifications w/ minimum allowable room\*

5x5 – 94"x68"x98" tall\*

7x7 – 110"x86"x98" tall\*

Weight w/ 8ft tower - 760lbs.\*

Weight w/ 8ft tower - 1110lbs.\*

Required tools for install: Ladder, Ratchet, 14mm socket, 19mm socket, 14mm wrench, shears (for strap cutting)

## Blinds with 8ft legs

The legs will be loose from the blind.

Remove the provided bolt packet from inside the blind and place aside.

Using the intergraded forklift slots, lift the blind enough to place leg stud bolts (larger 19mm bolts in package) into the nuts that are welded onto the leg studs.

Lifting to appropriate height, start inserting the legs making sure the foot pads are facing out.

Tighten the bolts just enough to hold legs secure until the blind is in position.

Once all legs are secure enough to hold the legs in place, lower blind into position and prepare to secure bracing. Do not tighten the leg studs yet.

Take bracing and loosely bolt on bracing using the supplied 14mm bolt sets.

Kick out the legs and make sure the blind is level, then proceed to tighten all the leg stud bolts and the bracing bolts.

## The Staircase

The staircase is separate from the blind.

Lift the top of the staircase up to the blind porch and using the supplied 14mm bolts, loosely bolt the top of the staircase then the bottom of the staircase supplied mounting holes, these are elongated to allow for uneven surfaces.

You can lift the bottom of the staircase to allow the staircase to settle out level.

Once complete you can now tighten the bolts.

## Securing blind in position

In the event you are wanting to secure your blind in position, we have provided holes in the footpads for stakes (not provided) and there is a central location on the bottom of the blind frame for securing a cable tie-down system (not supplied).

\*\*All weights and measurements are approximate