



Assembly Instructions

Stainless Steel Mirror Cabinet

Parts Supplied	Fittings Supplied	
1 x MIRROR CABINET	 4 x SCREWS (32mm)	 4 x WALL PLUGS (ø6*28mm)

Tools Required (Not Supplied)

Cross Head Screwdriver
Power Drill
6mm Masonry Drill Bit

Before You Start

- Check the pack and make sure you have all of the parts listed above.
- When you are ready to start, make sure that you have the right tools to hand, plenty of space and a clean dry area for assembly.

ASSEMBLY

CAUTION:

Before drilling into any walls, check that there are no hidden cables or pipes. Use caution when using power tools near water. We recommend the use of a Residual Current Device (RCD).

Please make sure that the surface is suitable for installation of the cabinet and the fastening devices will withstand the forces generated by the loaded unit.

Do not fix to newly plastered or wallpapered walls as chemical reactions can cause discolouration of the surface finish. When working near a basin or bath, insert the plug into the waste to avoid the possibility of losing any small parts.

Using a spirit level and the cabinet as a template, mark the drill holes in the required location. Always double check the position and your measurements of the product before drilling the holes. MEASURE TWICE, DRILL ONCE!

NOTE: The wall plugs and screws supplied are for use with solid walls. Please ensure you use the correct wall plugs for your wall type. If in doubt seek professional advice.

CARE & USE

Wipe clean with a soft damp cloth. Never use scourers, abrasives or chemical cleaners.
