Installation Instruction

BV Better Vanity

PARTS LIST

NO.	PARTS	NAME	QTY	NO.	PARTS	NAME	QTY
①		Hangs board	1	④		Cabinet body	1
②		M4x60 Countersunk head screw	2	⑥		M6x65 Screw	2
③		25x25x430 Aluminum bar with holes	3	⑦		Basin	1
④		M 4 x 14 Flat head tapping screws	6				

A 1:3

Installation Steps ①

Please make sure to install screws on the solid part.

26.97

Install hangs board by ② ①

②

Hang up the cabinet

B 1:3 ③

Fix the cabinet by ⑥

④

Install the basin

⑤

Finished