

JPM COACHWORKS INSTALLATION GUIDE

2015+ FORD MUSTANG BRAKE BOOT

Pre-Installation Warning:

The installation of this product requires adhesives for proper assembly. Please read and follow all safety instructions regarding handling and proper ventilation of any adhesive you have chosen to use. You may also choose to purchase installation service from JPM Coachworks.

Required Tools/Supplies:

1. High temp adhesive (spray or brush on). Recommended products include the following:
 - DAP Weldwood HHR
 - 3M Super Trim Adhesive
 - Permatex Headliner & Trim Adhesive
 - 3M #90
2. Small flathead screwdriver (1/4" head or smaller)
3. Masking tape or blue painter's tape.
4. Knife, scissors, or angle cutters
5. 7mm socket with ratchet.

STEP 1

Remove the shift knob, boot, and the two front trim pieces on the console, which are highlighted with arrows in the diagram. Remove two 7mm screws behind each trim panel and lift the panel up and out of the vehicle. Remove the two 7mm screws at the base of the brake boot trim ring.



STEP 2

Lift the boot over the handle of the brake and cut the white zip tie holding the boot on. Remove the boot assembly from your vehicle and place it on a clean work surface.



STEP 3



Peel away the boot from the trim ring. You may need a small flat head screwdriver to help get the edges started.

STEP 4

Apply adhesive to the trim ring. Nothing will be visible afterward so don't worry about overspray.



STEP 3



Turn your new boot inside out and apply adhesive to the base. Be **extremely** careful to not get any adhesive on the surface of your new boot as some adhesives are impossible to remove from Alcantara or leather. You can mask off the inside of the boot with tape to prevent overspray if necessary.

STEP 5

Allow the glue to become tacky. The glue should not be wet to the touch or it will not take hold. Start adhering the new boot by aligning the front seam line to the front of the trim ring and pressing down. Do not lay the sides down until after the next step.



STEP 6



Adhere the back seam to the trim ring. The back edge of the boot should stop halfway down the wall of the trim ring.

STEP 7

Fold the edges down as shown in the picture and work your way down each side until the boot is completely installed onto the ring.



STEP 8



Turn the boot inside out and slide it over the parking brake handle.

STEP 9

Use a zip tie to fasten the boot to the handle and reinstall the surrounding trim pieces in the reverse order from which they were removed. Enjoy your new boot!



Thank you for your purchase from JPM Coachworks!

Please be sure to care for item properly. Leather products require cleaning and conditioning to maintain their soft feel and to keep from drying. Alcantara products tend to attract dust over time so quick wipes with a damp microfiber cloth will help keep them clean. Check our website for Alcantara cleaner and other supplies to keep your interior clean and fresh.

If you have any questions regarding this or any other product, please feel free to contact us through email or by telephone. If you are sending your items in for installation, make sure you have selected the installation service on your product page or that you have purchased it separately. Also, include a copy of your order with your item so that it can be identified easily.

JPM Coachworks, LLC
1600 Wilson Way SE, Suite 12
Smyrna, GA 30082
770-293-2120
sales@jpmcoachworks.com