

# JPM COACHWORKS INSTALLATION GUIDE

## 2015+ FORD MUSTANG CENTER CONSOLE

### Pre-Installation Warning:

The installation of this product requires adhesives for proper assembly. Please read and follow all safety instructions regarding handling and proper ventilation of any adhesive you have chosen to use. You may also choose to purchase installation service from JPM Coachworks.

### Required Tools/Supplies:

1. High temp adhesive (spray or brush on). Recommended products include the following:
  - DAP Weldwood HHR
  - 3M Super Trim Adhesive
  - Permatex Headliner & Trim Adhesive
  - 3M #90
2. Small flathead screwdriver (1/4" head or smaller)
3. Razor blade or sharp knife.
4. T20 Hex bit or hex wrench
5. Needle nose pliers
6. (OPTIONAL) Pneumatic staple gun with 1/4" length staples

## STEP 1

Remove your factory console lid from your vehicle and place it on a clean work surface.



## STEP 2

Remove the release levers by unscrewing the two T20 hex screws from the base of the console lid.



### STEP 3



Remove the staples around the perimeter with a small flat head screwdriver. You may need pliers to completely remove them. Once all of the staples are out, you can remove the factory cover.

### STEP 4

Apply adhesive to the fabric side of the provided foam and to the top of the console. Allow time for the adhesive to become tacky. The adhesive should not be wet to the touch or it will not take hold.



### STEP 3

Lay the foam over your console pressing the edges down and stretching it where needed for a tight fit.



### STEP 5

Using a razor or sharp knife, trim the excess foam by following the edge of the console with your blade.



## STEP 6



If you are not using a staple gun for attachment of your new cover, apply adhesive to only the outer portion of your new cover and only the inside edge of the console lid. Allow the adhesive to become tacky. Align the seam lines so that they correspond with the small indentions on the center of the front and rear edge of the console lid.

## STEP 7

Start fastening the new cover to the rear edge of the console at the seam line. Pull the front edge as tight as possible before fastening it down. After the front and rear are fastened, work your way down the sides pulling outward to remove any slack from the top of the lid. You should pull the sides equally at the same time to maintain a straight seam line on the top surface.



## STEP 8



Cut the cover at the corners of the button recess to allow it to fold in easily. Do not cut all the way to the edge or the cut will be visible once folded.

## STEP 9

Press the edges of the cover down to allow the adhesive to take hold. If additional adhesive is required, be extremely careful not to get any overspray on the surface as it may not be removable. Masking tape on the surface will help with potential overspray.



## STEP 10

Reinstall the release lever and reinstall the lid back into your car. Enjoy your new cover!



Thank you for your purchase from JPM Coachworks!

Please be sure to care for item properly. Leather products require cleaning and conditioning to maintain their soft feel and to keep from drying. Alcantara products tend to attract dust over time so quick wipes with a damp microfiber cloth will help keep them clean. Check our website for Alcantara cleaner and other supplies to keep your interior clean and fresh.

If you have any questions regarding this or any other product, please feel free to contact us through email or by telephone. If you are sending your items in for installation, make sure you have selected the installation service on your product page or that you have purchased it separately. Also, include a copy of your order with your item so that it can be identified easily.

JPM Coachworks, LLC  
1600 Wilson Way SE, Suite 12  
Smyrna, GA 30082  
770-293-2120  
sales@jpmcoachworks.com