Modular Paint Rack 35mm 45°










Use an exacto knife to cut the bits connecting the parts to the frame.



Always dry-fit the parts to together without any glue to make sure you are assembling the correct parts.



Remove the parts from the frame with a rotating motion along the axis formed by the bits you just cut.



Use a drop of glue along the joints and hold it in place until the glue has sufficiently dried.



Press the parts together or use a hobby hammer with slight force for assembly.

