

ASSEMBLY INSTRUCTIONS FOR THE HOLLYWOOD PS-6 BIKE VALET PARKING SYSTEM

LIST OF MATERIALS:

<u>Qty</u>	<u>Description</u>
2	Side Angle Braces
2	Straight Braces
1	Parking Frame
1	Poly Bag containing the following parts:
8	1/4 - 20 x 2-1/2" bolts
8	1/4 - 20 self locking nuts
16	1/4" SAE washers

Tools required for assembly:
Two 6" adjustable wrenches



ASSEMBLY PROCEDURE:

1. Align the parking frame with the center holes, of the side angle braces
2. Align the straight braces with the holes on the side angles, insert bolts.
3. Tighten all bolts and nuts securely.

Limited One Year Warranty: This rack is warranted for a period of one year against defects in materials and workmanship, effective from the date of purchase to the original purchaser. The manufacturer will repair or replace any defective parts due to materials or workmanship. The manufacturer of this product shall not extend the warranty to 1) Any failure or malfunction of the product do to any of or modifications to the product; or 2.) Damages not attributable to a defect in materials or workmanship; or 3.) Damages resulting from improper installation on vehicle or attachment of bicycles on rack.

Consequential or Incidental Damages: The manufacturer shall not be liable for any consequential or incidental damages in connection with the purchase, use or handling of this bike rack. **Purchaser's Rights:** Some states do not allow the exclusion or limitation of consequential or incidental damages and the above limitation may not apply to you. This warranty gives you specific legal rights and you have other rights, which vary from state to state.

Hollywood Engineering Inc.
12812 S Spring Street Los Angeles, CA 90061
(800) 747-4085 or (310) 516-8600 FAX (310) 516-8955
www.hollywoodracks.com Made in Taiwan