



For a complete Peace of Mind Installation Guide

Bidets and Bidet douches should be installed in accordance with Australia Standard AS3500 Section 10A

Plumber Guide

10A.2.3 Toilet seat douches

Hand Sprays shall be installed in accordance with The National Construction Code – Volume Three and where used as a douche spray are classified as High Hazard and appropriate additional backflow prevention will be required such as RPZ valve.

Plumbing Info

Although the manufacturer has designed this product for easy installation, in other countries most people do it themselves. In Australia, the plumbing code mandates that this product needs to be installed by a plumber and we do advise that you comply.

*Same rules apply to other household products like washing machine, fridges with water connection and any water filter or appliance connected to a water tap.

Installation Information: For installation refer to The National Construction Code – Volume Three. Where the hand spray is used as a douche spray the application is classified as High Hazard and appropriate additional backflow prevention will be required such as RPZ valve.



Step 1

Most toilet have a flex pipe



Step 2

Remove Flex Pipe



Step 3

Place dual check on tap, ensuring you insert into the bottom of the backflow dual check.



Step 4

Fit handspray hose to water diverter, ensuring you insert black washer.



Step 5

Fit water divert-er to cistern, ensuring you insert black washer



Step 6

Connect flex pipe