

INSTALLATION INSTRUCTIONS

2500/3500 Outback Kitters Shock Guard Installation Procedure

NOTE: FAILURE TO INSTALL THIS PRODUCT AS SPECIFIED IN THE INSTALLATION PROCEDURE WILL VOID ALL WARRANTY. IF ANY PARTS HAVE ARRIVED DAMAGED OR WERE NOT SUPPLIED IN THE KIT, PLEASE TAKE PHOTOS AND THEN PROCEED TO CONTACT YOUR SUPPLIER.

IN THE BOX

- 2 x Outback Kitters Shock Guards
- 1 x Bolt kit

TOOLS REQUIRED

- 13mm spanner
- 13mm socket
- Ratchet/electric ratchet
- A hoist or jack + jack stands is recommended



OVERLANDING
THE AUSSIE WAY



NOTE: FAILURE TO INSTALL THIS PRODUCT AS SPECIFIED IN THE INSTALLATION PROCEDURE WILL VOID ALL WARRANTY. IF ANY PARTS HAVE ARRIVED DAMAGED OR WERE NOT SUPPLIED IN THE KIT, PLEASE TAKE PHOTOS AND THEN PROCEED TO CONTACT YOUR SUPPLIER.

1

1.1

Sit the Outback Kitters shock guard up against the bottom of the shock bracket on the rear axle and line up the mounting holes.

Refer Image 1.



Image 1

1.2

Using a M8 bolt, M8 washers and M8 lock nut supplied in the kit, secure the rear hole of the shock guard first and leave it loose.

Refer Image 2.



Image 2

2

2.1

Using the last M8 bolt, M8 washers and M8 lock nut supplied in the kit, proceed to secure the front hole in the Radflo shock guard.

Refer Image 3.



Image 3

2.2

Once both bolts are in, using a 13mm spanner and 13mm socket on a ratchet, tighten both bolts.

Refer Image 4.



Image 4

Once bolts have been tightened, the installation of the shock guards are now complete.

NOTE: FAILURE TO INSTALL THIS PRODUCT AS SPECIFIED IN THE INSTALLATION PROCEDURE WILL VOID ALL WARRANTY. IF ANY PARTS HAVE ARRIVED DAMAGED OR WERE NOT SUPPLIED IN THE KIT, PLEASE TAKE PHOTOS AND THEN PROCEED TO CONTACT YOUR SUPPLIER.