

## INSTALLATION INSTRUCTIONS

### RAM 1500 DT WINCH ISOLATOR BRACKET INSTALLATION PROCEDURE

NOTE: FAILURE TO INSTALL THIS PRODUCT AS SPECIFIED IN THE INSTALLATION PROCEDURE WILL VOID ALL WARRANTY. IF ANY PARTS HAVE ARRIVED DAMAGED OR WERE NOT SUPPLIED IN THE KIT, PLEASE TAKE PHOTOS AND THEN PROCEED TO CONTACT YOUR SUPPLIER.

#### IN THE BOX

- Winch isolator bracket
- 1 x Bolt kit
- 2 x Isolator terminal insulators

#### TOOLS REQUIRED

- Ratchet/electric ratchet
- 10mm socket/spanner
- Clip removal tool



**OVERLANDING  
THE AUSSIE WAY**



NOTE: FAILURE TO INSTALL THIS PRODUCT AS SPECIFIED IN THE INSTALLATION PROCEDURE WILL VOID ALL WARRANTY. IF ANY PARTS HAVE ARRIVED DAMAGED OR WERE NOT SUPPLIED IN THE KIT, PLEASE TAKE PHOTOS AND THEN PROCEED TO CONTACT YOUR SUPPLIER.

# 1

### 1.1

Start by removing the 2 clips on the radiator plastic shroud and carefully manipulate the shroud out from the front fender. Retain the clips for later use.

*Refer Image (1 and 2)*



Image 1



Image 2

# 2

Remove the 2 Oem bolts shown and retain the grey bolt securing the headlight for later use.

*Refer Image (3 and 4)*



Image 3



Image 4

NOTE: FAILURE TO INSTALL THIS PRODUCT AS SPECIFIED IN THE INSTALLATION PROCEDURE WILL VOID ALL WARRANTY. IF ANY PARTS HAVE ARRIVED DAMAGED OR WERE NOT SUPPLIED IN THE KIT, PLEASE TAKE PHOTOS AND THEN PROCEED TO CONTACT YOUR SUPPLIER.

2

Remove the 2 Oem bolts shown and retain the grey bolt securing the headlight for later use.

*Refer Image (5 and 6)*



3

Manipulate the plastic radiator shroud back into place and resecure with the clips removed in step 1..

*Refer Image (7)*



**INSTALLATION OF THE OUTBACK KITTERS  
RAM 1500 DT WINCH ISOLATOR  
IS NOW COMPLETE**

NOTE: FAILURE TO INSTALL THIS PRODUCT AS SPECIFIED IN THE INSTALLATION PROCEDURE WILL VOID ALL WARRANTY. IF ANY PARTS HAVE ARRIVED DAMAGED OR WERE NOT SUPPLIED IN THE KIT, PLEASE TAKE PHOTOS AND THEN PROCEED TO CONTACT YOUR SUPPLIER.