



2015 Honda Rubicon – Foreman Rancher

And older models

Thank You for considering or buying the SawGrip ATV Chainsaw Carrier
info@sawgrip.com

INSTALLATION

Remove all hardware and detach bar clamp from mounting plate. Place mounting plate, FIG 1, on top of cargo rack and slide under front cargo rack stop rail. Adjust plate until finished mounting hardware can be placed in appropriate slots. Install hardware to mounting plate depending on model and tighten. Care should be taken with UBolts when tightening so not to break them. Some models require drilling a 5/16" hole for mounting. After mounting plate is installed, place bar clamp onto mounting plate and install the 2 5/16" bolts to secure it.

EXCESSIVE tightening will break the UBolts.

SET RESISTANCE

After the SawGrip is bolted to the ATV rack, open the bar clamp enough so chainsaw bar will go between the rubber pads. Tighten the 2 bottom lock nuts leaving about 1/8" or less gap. (FIG 4) then tighten top T-handle until snug. Pull on saw. If the saw moves easily in or out you may have to tighten the bottom 2 lock nuts more. Once the right tension is applied you can put the saw in or out by just loosening the top T-handle. No other tightening should be needed to the 2 bottom nuts. It is recommended to remove saw from the SawGrip before transporting ATV on trailer or any other means of transportation. If long trips are planned with your ATV we suggest you tighten the top T handle securely so that the saw is held firmly.

Total chainsaw length must not exceed the width of the ATV.

2015 HONDA RUBICON – FOREMAN – RANCHER AND OLDER MODLES

