

Corn Shield Mounting Instructions

Case IH 2200/2400/3200/3400

New Holland 96C/96D/98C/98D

1. Position the Corn Shield on the poly point for best fit.
2. Once in position, mark around the base of the Corn Shield.
3. Measures the locations of nuts molded into the Corn Shield and transfer them to the poly point.
4. Drill (3) 3/8" holes at the locations marked in step #3.
5. Screw the (3) 5/16" x 2-1/2" threaded rods into the nuts on the bottom of the Corn Shield.
6. Place Corn Shield on the corn head with the rods through 3/8" holes just drilled.
7. Secure the Corn Shield to the corn head using the supplied fender washers and nuts.
8. The flap may need to be trimmed to lay flat on the divider point.



MAY WES
Original Poly People
A DIVISION OF PRIDE SOLUTIONS

120 Eastgate Drive SE
PO Box 7
Hutchinson, MN 55350

1-800-788-6483
1-320-587-2322
1-320-587-6112 (Fax)

WWW.MAYWES.COM