

Solar Storm, ESB, Sunlite, Sunfire, Solar Wave Tanning Bed Acrylic & Lamp Removal Instructions

Warning!!! Disconnect from electrical power before servicing.

Removal of Acrylic

Remove black acrylic locking strips first. To remove the acrylic locking strip, insert a flat head screwdriver into the front edge of the locking strip and pry up. After Acrylic locking strip is removed, go to the head of the bed.

Place the flat head screwdriver between the acrylic and aluminum extrusion.

You will then lift the acrylic up enough to get your hand under it.

Please use a glove due to the acrylic is very sharp and will cut an unprotected hand.

With your hand placed between the acrylic and extrusion, lift up on the acrylic until it pops out of the extrusion.

Lift the acrylic out of the bed.

Replacing Acrylic

Insert Acrylic into aluminum extrusion lip in back of bed. Apply pressure to back aluminum extrusion while pushing acrylic down into the bed until it pops into the front aluminum extrusion.

Replace black acrylic locking strips.

Lamp Removal & Re-installation

Most Lamps are rated for between 800-1000 hours of use. You may elect to change lamps sooner.

Step 1. After removing the acrylic, grasp a lamp at one end and at middle. Turn the lamp a quarter turn. The lamp may then be gently removed from its holder.

Step 2. Hold lamp with brand name label facing toward the acrylic. To install the lamp, insert the pins located on the ends of the lamp into the slots on top of the lamp holder and turn the lamp a quarter turn to hold in place. Make sure that the writing on the lamp faces the acrylic.

****Lamps used longer than 1000 hours have lost their tanning power even though they will continue to light.**

