



- 1** 4Link bars. Remove factory hangers. Drilling out the factory rivets can be difficult, and you may have to heat with a torch, then punch out



- 2** Install Lower bag mounts on top of axle. 4Link bars will attach to lower bag mounts. Relocate factory shocks, or buy replacements from us #1321 Loop/Loop for rear.



- 3** Install pan hard bar. Heim Joint installs on bottom of Pass bag mount. Bracket end installs on frame rail.

- 4** Attach bags, and install the upper bag plates, making sure there is no metal contact through out the travel.