



WHITESDRYWEAR.COM

How to install the Pocket Support System

1. Remove the bungee locks from all bungee cords. Do this by pulling on the bungee lock's circular tab and sliding it off.
2. Unzip the main entry zipper covering the dry zipper. Do NOT unzip the dry zipper.
3. Below the dry zipper, completely unzip the lower right and left zippers.
4. Pull the inner layer (drysuit core) up and away from the outer layer (drysuit skin), exposing the four loops located at the waist (two at the waist front, two at the waist back).

INSTALL THE BUNGEEES

5. Locate one of the MOLLE Plates on the outer layer (drysuit skin). From the interior of the outer layer (drysuit skin), route two ends of bungee cords out the center hole of the MOLLE Plate.
6. Route both bungee cords through the center hole of the pocket back, into the internal pouch, and out the top of the pocket.
7. Reattach the bungee lock to the bungee cords exiting the top of the pocket. Do this by pulling the bungee lock's circular tab up and pushing the bungee cords through the bottom right and left sides. Holding both ends of the bungee cords, tie a simple overhand knot near the ends.
8. On the inner layer (drysuit core), locate the four loops located at the waist (two at the waist front, two at the waist back). From the interior of the outer layer (drysuit skin), locate the two bungee clips. Attach one clip to a front loop and one clip to the back loop. Make sure the clips are attached on the same side.
9. If you will be installing two pockets, follow steps 5-8 to attach the bungees on the other side.

REASSEMBLE THE DRYSUIT

10. Push the inner layer (drysuit core) back into the outer layer (drysuit skin).
11. Below the dry zipper, find the lower right and left zippers. Find the right and left zipper on the outer layer (drysuit skin). Zip up the right and left zippers. Zip up the main entry zipper.

INSTALL THE POCKET(S)

12. On the backside of the pocket(s), take the webbing straps and alternate weaving through the MOLLE Plate slots and webbing on the pocket back.
13. Fold the VELCRO™ Brand tabs up and secure with the VELCRO™ Brand booklets.

ADJUST THE POCKET SUPPORT SYSTEM

13. Put your drysuit on, with nothing in the pocket(s). Open the pocket(s) and pull on the bungee ends while holding the bungee lock. Adjust the bungees so they provide some tension. Do not overtighten.
14. Tuck the bungee lock and excess bungee cord into the internal pouch.

Your Pocket Support System is now ready to use!

WHITESDRYWEAR.COM

