



## Can-Am Commander Windshield/Top

### Installation Instructions

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Enclosure**.

**Step 1:** Remove your 3SI UTV cab enclosure and Velcro kit from the shipping box. Contents are as follows:

-Windshield/Top.

-Adhesive Velcro kit. Contents of the Velcro kit and placement info are shown in the following table.

Adhesive Velcro Kit		
Windshield Top		
A	2-8"	Top of rear roll bar upright-Horizontal around roll bar-double sided strap wraps around
B	2-8"	Middle of side roll bar-Horizontal on bottom side of bar-holds webbing tab in place
C	2-8"	Top of front roll bar upright-Vertical-holds webbing tab in place
D	2-8"	Middle of front roll bar upright-Vertical-holds webbing tab in place
E	2-4"	Bottom of front roll bar upright-Vertical-holds sewn-in loop in place

An additional strip of 2" Velcro has been included in your shipment if needed. The formal name for Velcro is hook and loop. The hook side is rough and the loop side is soft. The strips listed above are hook. The corresponding loop strips are sewn into your enclosure. **If you struggle with placement of the adhesive hook strips, while holding the enclosure on the cab frame, match the placement of the adhesive hook to the sewn in loop strips on the enclosure.**

***Note: before applying adhesive Velcro Strips to your vehicle, surfaces should be free of dust, dirt and oil. Clean vehicle surfaces with water or Windex only. Do not use solvents to prepare your vehicle surfaces for Velcro application.***

**Step 2:** Begin installation of the adhesive Velcro to the cab frame. Again, at any time you struggle with placement, hold the enclosure to the cab frame and match the adhesive Velcro hook to the sewn-in Velcro loop. The following pictures show the approximate locations to apply the adhesive Velcro hook. Also, refer to the Velcro Kit contents on pages 1 and 2 for placement description.

### Windshield/Top



**Step 3:** After all adhesive Velcro strips are attached, begin attaching enclosure starting with the back panel. Align and square the back panel to the cab frame as you connect the Velcro strips.

*Note: The middle/top of the back panel wraps around the cross bar from the inside of the bar.*

**Step 4:** Place the windshield/top on the cab frame. If necessary, remove and re-attach adhesive Velcro strips to match sewn-in Velcro loop.

**Step 5:** Starting in the back corner, wrap the double-sided Velcro strips around the adhesive Velcro strips on the rear roll bar uprights.

**Step 6:** Continue attaching the sewn-in Velcro strips to the adhesive strips on the cab frame. As you attach the Velcro, tighten the enclosure to the frame by pulling the enclosure tight from side to side and front and back.

**Step 7:** Fasten pre-attached Enclosure Front Hood Straps to front bumper as shown in the following picture. Bringing the end of the straps up to the latch buckle, run the end through the back of the top buckle opening first and then through the front of the lower buckle opening. **DO NOT FULLY TIGHTEN FRONT HOOD STRAPS AT THIS TIME.**



**Step 8:** Repeat all steps necessary to align and tighten the enclosure to the cab frame.

**Step 9:** Tighten the hood straps.

**See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.**





## Care Instructions

### Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

### Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

### Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

### Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the full cab enclosures and door/rear window combos should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. REMOVE BEFORE HAULING.