



3 STAR INDUSTRIES

CFMOTO ZFORCE 800

WINDSHIELD

**DO NOT REMOVE
PROTECTIVE PAPER FROM
WINDSHIELD THIS WILL BE
YOUR LAST INSTALLATION
STEP!**

STEP 1

Assemble wingnut, neoprene washer and bolt.



STEP 2

Wrap loop clamps around the roll bar, flat part of the clamp facing outward and resting on the windshield.



Part	Qty	Description
	4	1 3/4" Loop clamp
	4	Neoprene Washer
	4	1 1/2" Bolt
	4	Wingnut
	4	Small Washer
	4	Lock Nut
	40"	GASKET

STEP 3

Set windshield on the hood line, peel back protective paper enough to expose the clamp holes, line up holes in windshield with holes in clamps.



STEP 4

Insert wingnut, neoprene washer and bolt assembly through the front of the windshield, then through the clamp holes.



STEP 5

Secure with small washer and lock nut. Repeat these steps for both bottom clamp holes. Hand tighten only at this time.

We have provided a roll of adhesive gasket for the top portion of the windshield. Gasket will prevent the windshield from vibrating against the roll bar.





STEP 6

Tighten all hardware and remove the protective paper from both sides of the windshield.