



CF MOTO UFORCE 600

2 Pc Polycarbonate Windshield with Straps

Installation Instructions

You have just purchased the best Polycarbonate Windshield for your Utility Terrain Vehicle available on the market today. Your Windshield is made of ¼" gauge polycarbonate (Lexan) that is almost unbreakable. With proper installation and care you can expect many years of service life from your **3SI UTV Polycarbonate Windshield**.

Step 1: Remove your 3SI UTV Polycarbonate windshield kit from the shipping box. **DO NOT REMOVE PROTECTIVE PLASTIC PAPER FROM THE WINDSHIELD AT THIS TIME. THIS SHOULD BE YOUR LAST INSTALLATION STEP.**

Contents: Polycarbonate Windshield Top and Bottom

4 – 12" Velcro Straps

2 - C-Clamps and 1-1/2" Bolts

2 – Small Washers, Lock Nuts, Thumb Screws and Neoprene Washers

Step 2: Pull the protective paper from each edge of the windshield to expose the slots for the clamp screws.

Step 3: Hold the lower section of the windshield to the front roll bars. The lower portion of the windshield should rest behind the hood.

Step 5: Set bottom portion of the windshield in place resting on the inset rollbar. Hook clamp around the roll bar and use a bolt with wing nut and washer through the front of the windshield and through the hole in the clamp, secure with small washer and lock nut. Hand tighten only!



Step 6: When both clamps have been attached tighten the lock nuts.

Step 7: Set top portion of windshield on the bottom portion.

Step 8: Pull protective paper back on both sides to expose slots. Thread strap through the front of the windshield with soft Velcro facing the interior of the machine, wrap strap around the bar pull tight and attach hook to loop. Repeat this process for all remaining straps.

Step 9: Remove the protective plastic paper from each side of your windshield.





**Do not wipe windshield with cotton tshirt, dish towel or micro fiber.
Use micro fleece cloth only!**

Lexan Cleaning Recommendations

- Use water hose to spray off chunks of mud and dirt.
- Use dish soap mixed up with water and pour on windshield and rinse.
- Use micro fleece cloth to wipe away spots.
- Use Mud Traxx ceramic detailer to wax your windshield. Use micro fleece to polish.

Important Instructions

- Never use abrasive or highly alkaline cleaner on Lexan polycarbonate materials.
- Never use aromatic or halogenated solvents like toluene, benzene, gasoline, acetone or carbon tetrachloride on Lexan polycarbonate materials.
- Use of incompatible cleaning materials with Lexan sheet can cause structural and/or surface damage.
- Contact with harsh solvents such as methyl ethyl ketone (MEK) or hydrochloric acid can result in surface degradation and possible crazing of Lexan sheet.
- Never scrub with brushes, steel wool or other abrasive materials.
- Never use squeegees, razorblades or other sharp instruments to remove deposits or spots.
- Do not clean Lexan polycarbonate in direct sunlight or at high temperatures as this can lead to staining.
- For all mentioned chemicals consult the manufacturer's material safety datasheet (MSDS) for proper safety precautions.