



Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.



Massimo MSU 500/700-Cub Cadet Challenger 500/700

Full Cab for Hard Windshield-Half Doors

Installation Instructions

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Cab Enclosure**.

The enclosures for the Massimo and Cub Cadet were designed to be modular. Each enclosure panel can be installed independent of the other panels. As a result, you choose your level of coverage. For cold weather, you have the option of full coverage. When warm, store the doors and back panel and leave only the top on.

Install the modular cab enclosure in the following order:

- Back Panel
- Doors
- Windshield/Top or Top

Step 1: Remove your 3SI UTV Cab Enclosure and Velcro kit from the shipping box.

Step 2: Place the enclosure over the vehicle's cab frame. Square and align the enclosure to the cab frame. Note the location of sewn-in loop strips in the enclosure. Adhesive hook strips will be attached to the cab frame corresponding to the loop strips. It may be necessary to remove your hard top before installing the back panel. Position the adhesive strips to allow the enclosure to fit tight to the cab frame. Remove the backing from the adhesive hook strips and install as indicated in the following adhesive hook tables and pictures.

BACK PANEL

Adhesive Hook Kit Contents/Placement		
Reference	Qty-Size	Placement

A	1-40"	At bottom of rear window panel, attaches to plastic guard behind lift bed
B	1-36"	At top of rear window panel, attaches at center top roll bar
C	4-8"	Goes around bar at curve in rear top of side roll bar
D	2-8"	Double side goes around bar at curve at the top of the rear roll bar
E	4-8"	Goes around rear of side roll bar at top & bottom of tab below seatbelt bracket
F	2-6"	Goes around rear of side roll bar in center of side handle bar
G	2-8"	Double side at bottom of rear roll bar above curve at bottom of bar
H	2-8"	Goes around rear of side roll bar at bottom most point below curve
I	1-8"	Goes around center of small roll bar between seats corresponding to double side at center below vinyl window



DOOR PANELS

Reference	Quantity/Size	Placement
A	2-8"	Double side at top Side Roll bar behind the bracket for center roll bar.
B	2-7" 2-27" 2-9"	Attach to rear roll bar below curve (only if using as door kit or w/o rear window). Goes around rear roll bar from curve at top to curve at bottom (only if using as door kit or w/o rear window). Attach to rear roll bar above the curve. (only if using as door kit or w/o rear window).
C	2-13"	Attach to diagonal roll bar below seats. (behind hinged factory door)
D	2-4"	Placed on outside of factory hinged door place corresponding to small Velcro piece just below magnet packet point of door.
E	2-8" 2-5" 4-3"	Attaches to plastic below seat in front of door latch on inside of door. Attaches to plastic below seat in rear of door latch on inside of door. On either side of door latch (placed vertically on inside of door)
F	2-9"	Attach partially on roll bar behind fender and partially on metal bracket in front of door hinge.
G	4-8"	Attaches at front side of roll bar, below the windshield and above the fender.
H	4-8"	Double side at corners of small window in front placed above and below side mirror bracket.
I	2-8"	Double side at curve of roll bar directly behind fender.
J	2-8"	At curve in front side roll bar (above windshield)
K	4-8"	In center of roll bar front above Velcro strap for windshield
L	4-8"	In center of top side roll bar (between the brackets)
M	2-8"	Attached on hinged factory door corresponding to magnet bar. *4" screws are enclosed to give the customer the option of mounting the bar to the door. It is not required but is suggested for best results.
N	2-6"	Goes around the side handle bar corresponding to the double side at rear of vinyl window.

****NOTE (this is optional) – at the top of the cutout for the latch under the bottom of the seat, the long double side will wrap around the bar and fasten to itself**



SOFT TOP

Reference	Qty-Size	Placement
A	2-6"	Wrap the adhesive hook strip horizontally around the front roll bars where indicated in the following picture. Wrap the bottom of the tension strap around the adhesive hook strip. If needed, loosen the tension strap to extend the length of the strap. DO NOT PULL TIGHT UNTIL ALL FOUR CORNERS ARE IN PLACE AND THE TOP IS PROPERLY ALIGNED.
B	2-6"	Wrap the adhesive hook strip horizontally around the rear roll bars where indicated in the following picture. Wrap the bottom of the tension strap around the adhesive hook strip. If needed, loosen the tension strap to extend the length of the strap. DO NOT PULL TIGHT UNTIL ALL FOUR CORNERS ARE IN PLACE AND THE TOP IS PROPERLY ALIGNED.

Step 3: After all adhesive hook strips are attached, begin attaching the enclosure to the cab frame. As you attach the hook and loop, square the enclosure to the frame. **PLEASE NOTE, FOR MAXIMUM ADHESION, ALLOW THE ADHESIVE HOOK TO ADHERE TO THE FRAME FOR 24 HOURS BEFORE PULLING AGAINST THE HOOK WITH THE LOOP STRIPS.**

Step 4: Repeat any steps necessary to achieve a snug fit on the cab frame.

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.



3 STAR INDUSTRIES

Care Instructions

Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**