



3 STAR INDUSTRIES

CAN AM DEFENDER AND DEFENDER MAX

2 PC WINDSHIELD

**DO NOT REMOVE PROTECTIVE PAPER FROM WINDSHIELD
THIS WILL BE YOUR LAST INSTALLATION STEP!**

Part	Qty	Description
	4	C-Clamp
	2	L-Bracket
	6	Neoprene Washer
	8	1-1/2" Bolt
	8	Small Washer
	10	Lock Nut
	6	Wingnuts

STEP 1:

Assemble bolt and nut for the L-Bracket. You will use 2 bolts and 2 lock nuts.

Attach lock nut to bolt and twist all the way down the thread.





STEP 2: Peel back paper on both sides to expose the bolt cut outs. Insert the nut and bolt through the factory cut circular opening in the roll bar frame brace.



STEP 3: Set L-Bracket over the end of the nut and bolt assembly. Use small washer and lock nut to secure L-Bracket to frame brace.

STEP 4

Assemble bolt, neoprene washer and wingnut.



STEP 5

Set lower portion of windshield on hood line. Peel back the paper on both sides to reveal pre-cut openings in the lower windshield. Insert washer/bolt assembly through the outside of the windshield and through the predrilled cut out. Then insert through the L-Bracket, secure with small washer and lock nut. Install both sides and tighten.



STEP 6

Set the upper portion of the windshield on top of the lower portion. As shown in the photo above.

STEP 7

Clip the C-Clamp on the outer edge of the pro-fit cage.

STEP 8

Insert bolt, washer and wingnut assembly through the outside of the windshield and through the pre-drilled cutout in the C-Clamp. Secure with small washer and lock nut.

STEP 9

Install all remaining washer/bolt assemblies, then tighten the lock nuts.





Cleaning Instructions.

Lexan, which is a brand of polycarbonate, is virtually indestructible. But it is also easily scratched. Please read the cleaning recommendations to limit damage to your product.

Never wipe your polycarb back panel with any just any old cloth. We recommend using micro fleece blanket. This is super soft material you can find at Walmart. Any other cloth even micro fiber will leave scratches on the polycarbonate. If you are unsure about the fabric please give us a call at 859-488-7447 ask for Sam.

Never use any abrasive cleaning products on your polycarb. Windex for example is not ok! This will cause the polycarb to develop a haze. Some chemicals may eat through the polycarb. I do not recommend using any kind of soap but if you must please use dish soap only, like dawn. Pour on and spray off, do not wipe!

Do not try to wipe off mud period! Spray mud and debris off with water hose first! If you have access to a leaf blower or air compressor we recommend using them to dry the windshield. If not, gently use a micro fleece blanket to blot the water away and then air dry.

I recommend using a product called NOVUS, to apply a coat of wax that will prevent mud and dust from clinging to your windshield. If you are having trouble finding this product online please call Sam at the number listed above.