



Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.



Honda Big Red Full Door/Rear Window Enclosure Installation

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Door/Rear Window Enclosure**.

Step 1: Remove your 3SI UTV Door/Rear Window Enclosure and Velcro kit from the shipping box.

Contents: 1 – Honda Big Red Door/Rear Window Enclosure

2 - 9" Velcro Strips (2 side of dash cowl)

2 – 4" Velcro Strips (2 side lower dash cowl)

2 – 34" Velcro Strips (Front Windshield Roll Bars- cutting required)

2 – 6" Velcro Strips (Front Windshield upper Roll Bar Corner)

2 – 12" Velcro Strips (Side Doors)

2 – 14" Velcro Strips (Side Doors Lower)

2 – 24" Velcro Strips (Top Door Side Roll Bar Cross-member)

2 – 8" Velcro Strips (Rear Roll Bar upright)

1 – 16" Velcro Strip (Rear Cab Frame lower)

1 – 15" Velcro Strip (Rear Cab Frame Lower)

1 - 37" Velcro Strip (Top Rear Roll Bar Cross-member)

Note: before applying adhesive Velcro Strips to your vehicle, surfaces should be free of dust, dirt and oil.

**** It will be necessary to remove your hard windshield and hardtop prior to installing your Door / Rear Window Enclosure**

Step 2: Place Door / Rear Window Enclosure on top of Roll Bar Cage and align corner seams with outside center of roll bars.

Step 3: Place each Velcro Strip on its corresponding Velcro Tab on the Enclosure. DO NOT REMOVE PLASTIC BACKING FROM VELCRO STRIPS AT THIS TIME.

Step 4: Pull the Enclosure down tightly and align outside corner seams with the center of each Roll Bar. At this point Velcro Strips can be removed from Enclosure Velcro Tabs and attached to the Vehicle in the order shown below. Note Velcro Strips should be oriented to match its corresponding Enclosure Velcro Tab.

- A. Remove plastic backing and place 16" Velcro Strip at Lower Rear of Cab Frame
- B. Remove plastic backing and place 15" Velcro Strip at Lower Rear of Cab Frame
- C. Remove plastic backing and place 37" Velcro Strip on Top Rear Roll Bar Cross-member
- D. Remove plastic backing and place 8" Velcro Strips vertically on each Rear Roll Bar upright
- E. Remove plastic backing and place 24" Velcro Strips on each Top Door Side Roll Bar Cross-member
- F. Remove plastic backing and place 9" Velcro Strips on each side of the dash cowl
- G. Remove plastic backing and place 4" Velcro Strips on each side of lower dash cowl
- H. Remove plastic backing and place 34" Velcro Strips on each Front Windshield Roll Bar upright-
Note: cutting of these Enclosure Velcro strips and corresponding Enclosure Velcro tabs will be required to match Roll Bar Clamp bracket placement on existing hard Windshield.
- I. Remove plastic backing and place 6" Velcro Strips on each Top Front Windshield Roll Bar upright Corner
- J. Remove plastic backing and place 12" Velcro Strips on each Side Door
- K. Remove plastic backing and place 14" Velcro Strips on each Side Door Lower

Step 5: Begin attaching Enclosure by first squaring the back of the Enclosure to the Rear of the Cab frame and attaching the Lower Rear Cab Frame Enclosure Velcro tabs to the 15" & 16" Velcro strips.

Step 6: Pulling upward & outward on the 8" Rear Roll Bar upright Enclosure Velcro Tabs, attach Rear Roll Bar upright Enclosure tabs to installed 8" Velcro Strips and also attach 37" Velcro Tab to installed Top Rear Roll Bar Cross-member Velcro strip. This should straighten the back window section of the Enclosure.

Step 7: Attach the Top Door Side Roll Bar Cross-member Velcro tabs to the installed 24" Velcro Strips by pulling the Enclosure Velcro Tab over the upper Door Roll Bar Cross-member and installed Velcro Strip.

Step 8: Starting by attaching the Top Front Windshield Roll Bar Upright corner Enclosure Tabs to the installed 6" Velcro Strips pull downward on the front corner of the Enclosure and attach the cut 34" Velcro Strip on each Front Windshield Roll Bar upright. Note: when properly installed the leading edge of the Enclosure (with binding) should align in the center of the Front Windshield Roll Bar.

Step 9: Attach 9" Velcro Strips on each side of the dash cowl and 4" Velcro Strips on each side of lower dash cowl

Step 10: Zip Doors closed and attach Velcro Tabs to each 12" Side Door and 14" Side Door lower Velcro Strips.

Step 11: Repeat Steps 5, 6, 7, 8 & 9 until the Enclosure fits snugly to the Vehicle Roll Bar structure and the rear window is tight.

Step 12: Replace hard top and hard windshield

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.



3 STAR INDUSTRIES

Care Instructions

Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**