



Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.



Honda Big Red Mini/Summer Cab Enclosure Installation

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Enclosure**.

Step 1: Remove your 3SI UTV Enclosure and adhesive Velcro kit from the shipping box. The technical name for Velcro is hook and loop. Hook is the rough side and loop is the fuzzy side. Your enclosure has loop sewn to the enclosure at various locations. Adhesive hook is attached to the cab frame corresponding to the sewn-in loop. Your adhesive Velcro hook kit contents and placement is as follows:


Reference	Qty/Size	Placement
A	2-15.5"	Bottom of back panel/Either side of middle opening/Horizontal
B	2-8"	Middle of rear uprights/Outside edge/Vertical
C	2-6"	Near outer edge/bottom of back panel/Vertical wrapped around bottom cross bar corresponding to the double-sided Velcro straps
D	4-8"	Top and middle of front roll bar uprights/Inside edge/Vertical
E	2-4"	Bottom of front roll bar uprights/Inside edge/Vertical
F	2-4"	Bottom of wings/Horizontal

Note: *before applying adhesive Velcro Strips to your vehicle, surfaces should be free of dust, dirt and oil. We recommend cleaning the vehicle surface with Windex.*

Step 2: Place enclosure on top of the cab frame and align corner seams with outside center of roll bars. Pull the enclosure down until it is tight on the frame.

Step 3: Note the locations of the sewn-in Velcro loop strips. The adhesive Velcro strips will be applied to the cab frame corresponding to the sewn-in strips.

Step 4: One at a time, remove the backing from the adhesive Velcro strips and attach to the cab frame as indicated on page 1. The following picture shows the approximate location of the adhesive Velcro.



Step 5: Begin attaching the back of the enclosure by first squaring the back to the cab frame and attaching the sewn-in Velcro loop at the bottom of the rear panel to the 2 attached 15.5" strips and wrapping the double-sided Velcro straps around the bottom cross bar. Attach the sewn-in Velcro tab to the 2-8" vertical strips near the middle of the back roll bar uprights.

Step 6: Open the vehicle hood. Fasten the 4 pre-attached Enclosure Front Straps around the structural bars underneath the hood. Bringing the end of the straps up to the latch buckle, run the end through the back of the top buckle opening first and then through the front of the lower buckle opening. **DO NOT FULLY TIGHTEN FRONT HOOD STRAPS AT THIS TIME.**

Step 7: Pulling downward toward the front of the vehicle on the front corners of the enclosure, attach the 8" top and 8" middle Velcro tabs and then attach the lower 4" Velcro tabs to the installed Velcro strips on each front windshield roll bar upright. Note: when properly installed the windshield should be centered between the front roll bar uprights. This step is best performed with an assistant tightening both sides of the front windshield at the same time.

Step 8: Attach the Side Dash Cowl 4" Enclosure Tabs to the installed Velcro Strips.

Step 9: Fully tighten Front Straps underneath the vehicle Hood until the Front Windshield is tight.

Step 10: Repeat any steps necessary until the enclosure fits snug to the vehicle roll bar structure and windows are tight as shown below.



See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.



3 STAR INDUSTRIES

Care Instructions

Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**