



Kawasaki Mule 3010 Windshield / Top Enclosure Installation

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Windshield / Top Enclosure**.

Step 1: Remove your 3SI UTV Windshield / Top Enclosure and Velcro kit from the shipping box.

Contents: 1 – Kawasaki 3010 Windshield / Top Enclosure

6 - 8" Velcro Strips (6 Front Cab Roll Bar Posts)

4 – 6" Velcro Strips (2 Rear Cab Roll Bar Posts, 2 Front Roll Bar Post bolt section)

Note: before applying adhesive Velcro Strips to your vehicle, surfaces should be free of dust, dirt and oil. Clean surfaces with water or Windex only. Do not use solvents to prepare your vehicle surfaces for Velcro application.

Step 2: Remove the clear plastic backing from the 8" Velcro strips and adhere vertically to the Front Cab Roll Bar Posts at 4 ¼", 15" and 27" above the front roll bar post bolts as shown in figures 2.1, 2.2 and 2.3.



Figure 2.1 - 8" Velcro strips placed vertically 4 ¼" above the front roll bar post bolts



Figure 2.2 - 8" Velcro strips placed vertically 15" above the front roll bar post bolts



Figure 2.3 - 8" Velcro Strips placed vertically 27" above the front roll bar post bolts

Step 3: Remove the clear plastic backing from the 6" Velcro strips and adhere horizontally around the Rear Roll Bar Posts 13" below the Roll Bar Cross member bolted section as shown in figure 3.1. Also place 6" Velcro Strips horizontally around the front Roll Bar Bolt Section as shown in figure 3.2. Note: Velcro Strips should go completely around the roll bar horizontally and the seam should face the cab interior. Repeat both sides.



Figure 3.1 – place 6" Velcro strips horizontally around the Roll Bar Post 13" below the rear Roll Bar Cross member bolted section



Figure 3.2 – 6” Velcro Strips placed Horizontally around the front Roll Bar Bolt Section

Step 4: Place the Windshield / Top Enclosure on top of the Roll Bar Cab Frame as shown in figure 4.1 and adjust so that enclosure seams are located near the center of the Roll Bars. Correct orientation is with enclosure hood straps in the front of the vehicle.



Figure 4.1 - Place enclosure loose on vehicle Cab Roll Bar Structure – Hood Straps to the front of the vehicle

Step 5: Attach Rear Cab Roll Bar Post enclosure Velcro tabs to installed Velcro strips as shown in figure 5.1. This should secure the top back section of the Enclosure. Repeat both sides.



Figure 5.1 - attach Rear Roll Bar Post Velcro Tabs around installed Rear Roll Bar Velcro strips

Step 6: Fasten pre-attached Enclosure Front Hood Straps to the center bar of the Vehicle front bumper as shown in figure 6.1. Bringing the end of the straps up to the latch buckle, run the end through the back of the top buckle opening first and then through the front of the lower buckle opening as shown in figure 6.2. DO NOT FULLY TIGHTEN FRONT HOOD STRAPS AT THIS TIME.



Figure 6.1 - run front hood straps through the center bar of the front bumper



Figure 6.2 - thread front hood straps into buckles

Step 7: Starting with the top Front Roll Bar Post Enclosure tabs pull outward and downward attaching tabs to 8" inch Velcro Strips on the Front Roll Bar as shown in figure 7.1. Repeat this process with the lower Front Roll Bar Enclosure Tabs as shown in figure 7.2 and 7.3 making sure that the Windshield is centered between the Roll Bar posts. Also attach front Roll Bar Bolt section Velcro Tab to the installed Bolt Section Velco strip horizontally around Roll Bar as shown in figure 7.4. Repeat both sides.



Figure 7.1 – attach top front Roll Bar Velcro Tab pulling outward and downward toward the front of the vehicle



Figure 7.2 - attach middle front Roll Bar Velcro Tab pulling outward and downward toward the front of the vehicle



Figure 7.3 - attach lower front Roll Bar Velcro Tab pulling outward and downward toward the front of the vehicle



Figure 7.4 - attach bottom front Roll Bar Bolt section Velcro Tab horizontally around Roll Bar bolt section of the Roll Bar

Step 8: Tighten Front Hood Straps by pulling downward from the buckle on both strap ends at the same time as shown in figure 8.1. Tighten both straps simultaneously until front windshield is tight



Figure 8.1 – fully tighten hood straps by pulling downward on both straps at the same time until front windshield is tight

Step 9: Repeat Steps 5, 7 and 8 until the Enclosure fits snugly to the Vehicle Roll Bar structure and front windshield is tight as shown in figure 9.1



Figure 9.1 - follow steps 5, 7 and 8 to fully tighten cab enclosure

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.