



Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For best adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a one size fits all product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.



Kubota RTV900 Windshield/Top Enclosure Installation

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your **3SI UTV Windshield / Top Enclosure**.

Step 1: Remove your 3SI UTV Windshield / Top Enclosure and Velcro kit from the shipping box.

Contents: 1 – Kubota RTV900 Windshield / Top Enclosure

4 - 10" Velcro Strips (Front Roll Bar Upright Posts)

2 – 7" Velcro Strips (Top of Rear Roll Bar Uprights)

Note:

Before applying adhesive Velcro Strips to your vehicle, surfaces should be free of dust, dirt and oil. Clean surfaces with mild soap and water only. Do not use solvents to prepare your vehicle surfaces for Velcro application.

Never fold your enclosure when it's removed. The vinyl will retain creases where folded. This will void all guarantees and warranties.

Step 2: Place Enclosure on top of Roll Bar Cage and align corner seams with outside center of roll bars. Take a moment to observe areas of the enclosure with sewn-in Velcro. Adhesive Velcro strips will be placed on the cab and frame corresponding to these areas.

Step 3: One at a time, remove the clear plastic backing from the 7" Velcro strips and fasten around each of the rear roll bar frame posts 13 1/4 inches below the top roll bar cross member brackets as shown in figure 3.1. Note: Velcro should make a complete circle around the roll bar placing the Velcro Seam toward the interior of the cab.



Figure 3.1 – Place Rear Velcro strips 13 1/4 inches below the top roll bar cross member brackets located at the top of the Cab Roll Bar Structure

Step 4: One at a time, remove the clear plastic backing from the 4-10" Velcro strips and attach VERTICALLY on the back side of the front roll bar uprights to correspond with the sewn-in Velcro tabs at either side of the windshield.

Step 5: Begin tightening the enclosure to the frame by pulling the back corners of the top down. Wrap the double-sided Velcro tabs around the adhesive Velcro strips at each corner as shown in Figure 5.1.



Figure 5.1 – Pull down firmly and attach rear Velcro Tabs to installed Velcro strips

Step 6: Pulling the Enclosure outward and downward toward the front of the vehicle attach the 10” Enclosure Windshield Velcro tabs to the Front Roll Bar Post upright Velcro strips as shown in figure 6.1.



Figure 6.1

Step 7: Fasten pre-attached Enclosure Front Hood Straps to the center bar of the Vehicle front bumper as shown in figure 7.1. Bringing the end of the straps up to the latch buckle, run the end through the back of the top buckle opening first and then through the front of the lower buckle opening as shown in figure 7.2.



Figure 7.1



Figure 7.2

Step 8: Repeat any steps as needed until the enclosure fits snug to the vehicle roll bar structure as shown in figures 8.1 and 8.2.



Figure 8.1



Figure 8.2

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.



Care Instructions

Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS.