



## Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

### SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little Windex works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

**PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.**



## Polaris Ranger RZR Full Cab for Hard Windshield Enclosure Installation

You have just purchased the best Enclosure for your Utility Terrain Vehicle available on the market today. Your Enclosure is made of Heavy Duty Fabric that is Water Repellent and resistant to Mildew, Ultra-Violet Sun Rays and Abrasion. With proper installation and care you can expect many years of long lasting fit, color and service life from your 3SI UTV Enclosure.

**Step 1:** Remove your 3SI UTV Enclosure and Adhesive Velcro kit from the shipping box.

ADHESIVE VELCRO KIT CONTENTS AND PLACEMENT		
Reference	Quantity/Size	Placement
A	2-5"	Middle of Rear Upright Roll Bars-Inside Edge-Vertical
B	2-30"	Back edge of doors-Vertical
C	2-28"	Bottom of doors-Horizontal
D	2-13"	Front/Bottom of doors-Vertical
E	2-12"	Bottom of wing-Diagonal
F	2-30"	Front roll bar uprights-Inside edge-Vertical-Cut to accommodate clamps
G	1-60"	Top of windshield-Horizontal (OPTIONAL)
H	1-41"	Bottom of back panel-Horizontal

Before removing your windshield for enclosure installation, mark the location of all clamps on the front roll bars with chalk. The Velcro tabs running the length of the front roll bars will require cutting to accommodate the clamps. Cutting instructions are attached.

*Note: before applying adhesive Velcro Strips to your vehicle, surfaces should be free of dust, dirt and oil. Clean surfaces with water and mild soap only. Do not use solvents to prepare your vehicle surfaces for Velcro application.*

**WHEN STORING OR SHIPPING YOUR ENCLOSURE, NEVER FOLD IT. IF FOLDED, THE VINYL WILL RETAIN CREASES WHERE FOLDED. THIS WILL VOID ALL WARRANTIES AND GUARANTEES.**

**Step 2:** Place Enclosure on top of Roll Bar Cage and align corner seams with outside center of roll bars. Pull the enclosure down until it is tight on the Roll Bar Cage.

**Step 3:** Note the location of the sewn-in Velcro strips on the inside of the enclosure. The adhesive Velcro is attached to the cab frame to match the sewn-in strips. The picture below shows the approximate placement of the adhesive Velcro strips.



**Step 4:** With the exception of the 2-30" Velcro strips for the front roll bars (reference F), remove the backing and apply the adhesive Velcro strips as indicated in the ADHESIVE VELCRO KIT CONTENTS AND PLACEMENT table on page 1.

**Step 5:** The 2-30" Velcro strips for the front roll bars will require cutting for placement between the windshield clamps. Apply vertically along the inside edge of the front roll bar uprights.

**Step 6:** The sewn-in Velcro tabs running the length of the front roll bar uprights will require cutting to accommodate your windshield clamps. See the attached instructions titled CUTTING VELCRO TABS TO ACCOMMODATE CLAMPS.

**Step 7:** Begin attaching the enclosure by first squaring the back of the enclosure to the rear of the cab frame and working forward. Don't be afraid to pull the enclosure tight around the cab frame.

**Step 8:** Repeat any steps necessary to square, tighten, and align the enclosure to the cab frame.

**Step 9:** Re-install your windshield.

See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.



## Care Instructions

### Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

### Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

### Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

### Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**