







3 STAR INDUSTRIES

TUATARA

BACK PANEL

**DO NOT REMOVE PROTECTIVE PAPER FROM WINDSHIELD
THIS WILL BE YOUR LAST INSTALLATION STEP!**

Part	Qty	Description
	2	LEXAN SPACERS
	2	STAINLESS STEEL BOLTS
	2	6" STRAPS
	4	10" STRAPS

ADHESIVE VELCRO CHART		
A	1-56	Across roll bar behind the seats
B	2-17	On side bar below grab bar.

STEP 1

Red arrows indicate the areas where you will install the adhesive Velcro.

STEP 2

Attach lower back panel to UTV.



STEP 3

INSTALL PLOYCARB BACK PANEL

Hold the polycarb to the back of the cab frame. Insert 10" straps through the outside of the top slots, fuzzy Velcro face down. Wrap straps around the roll bar and pull the end of the strap through the plastic clip and attach it to itself.



STEP 4

INSTALL CENTER STRAPS

Use the 6" straps in the center slots. Insert the end of the straps through the inside of the back panel. Through the top slot and then through the bottom slot. Put the end of the strap through the clip and attach it to itself.

STEP 5

INSTALL THE FACTORY WASHER AND PROVIDED STAINLESS STEEL BOLT

Remove factory bolt and washer. Slide the lexan spacer in between the roll cage and lexan back panel. Insert the provided bolt and factory washer through the outside of the back panel, through the spacer and twist into the rollcage. Tighten down.

REMOVE PAPER FROM BOTH SIDES OF THE BACK PANEL.



Cleaning Instructions.

Lexan, which is a brand of polycarbonate, is virtually indestructible. But it is also easily scratched. Please read the cleaning recommendations to limit damage to your product.

Never wipe your polycarb back panel with any just any old cloth. We recommend using micro fleece blanket. This is super soft material you can find at Walmart. Any other cloth even micro fiber will leave scratches on the polycarbonate. If you are unsure about the fabric please give us a call at 859-488-7447 ask for Sam.

Never use any abrasive cleaning products on your polycarb. Windex for example is not ok! This will cause the polycarb to develop a haze. Some chemicals may eat through the polycarb. I do not recommend using any kind of soap but if you must please use dish soap only, like dawn. Pour on and spray off, do not wipe!

Do not try to wipe off mud period! Spray mud and debris off with water hose first! If you have access to a leaf blower or air compressor we recommend using them to dry the windshield. If not, gently use a micro fleece blanket to blot the water away and then air dry.

I recommend using a product called MuddTraxx Ceramic Detailer, to apply a coat of wax that will prevent mud and dust from clinging to your windshield. If you are having trouble finding this product online please call Sam at the number listed above.