



**RAM SLIDING MOLLE PANEL  
INSTALL INSTRUCTIONS  
2009-2018 RAM 1500  
2010-2023 RAM 2500-3500**

# PARTS REFERENCE GUIDE



**MAIN BRACKET**



**BED LOCK PLATE**



## STEP 1.

Locate mounting hardware included in packaging. Remove the bracket side (larger side) of slides from the panel by extending the bottom slide (smaller slide) fully while holding the blue latch down. For the upper slide (larger slide) extend the slide fully and pull up with your finger on the black tab located on the inside of the slide on the smallest track of the slide.

## STEP 2.

Using 2 of the supplied ¼-20 countersunk bolts, locknuts, and washers, bolt the upper and lower slides to the main bracket on the upper and lower slots. The longer slide goes on top, the shorter slide goes on bottom. Be sure to go through the fifth hole on the upper slide and the last hole on the lower slide. The bolts should be snug, but not tight. See FIG 1 for reference. Set this assembly aside until step 6.



**FIG 1**

## STEP 3.

Use a tape measure to measure 2 ½ inches from the edge of the bed towards the cab (FIG 2) and 6 ¼ inches from the floor of the bed towards the top of the bed. (FIG 3) Mark the location at the intersection of the two measurements.





**FIG 2**



**FIG 3**

#### **STEP 4.**

Use a tape measure to measure  $1 \frac{5}{8}$  inches from the edge of the bed towards the cab (FIG 4) and 16 inches from the floor of the bed towards the top of the bed. (FIG 5)  
Mark the location at the intersection of the two measurements.



**FIG 4**



**FIG 5**

#### **STEP 5.**

Using a 7/16 drill bit, drill a hole in each of the marked locations from steps 3 and 4. Install the supplied rivnuts in the holes using a rivnut tool.

#### **STEP 6.**

Place the assembly that was put together from step 1 into the truck bed as shown in FIG 6. Use two of the supplied  $\frac{1}{4}$  20 countersunk bolts to secure the slides to the end of the bed in the rivnuts.





**FIG 6**

**STEP 7.**

Adjust the location of the main bracket until the top tabs are level with the top rail of the bed (see FIG 6) and the center of the bottom tab is around 16 ½ inches from the edge of the bed towards the cab.

**STEP 8.**

Mark the location of the center of the slot on the bottom tab of the main bracket. Move the bracket out of the way and, using the 7/16 drill bit, drill a hole at the mark. Use a rivnut tool to install the supplied rivnut. Replace the main bracket.



**FIG 7**

**STEP 9.**

Use the supplied bed lock plates, 5/16 button head bolts, washers and locknuts to install the bed lock plates as shown in FIG 8 and FIG 9. (Note, the bolt location in the slot may vary from vehicle to vehicle.)





**FIG 8**



**FIG 9**

### **STEP 10.**

Take the MOLLE panel and slide the panel side of the slides into the bracket side of the slides. You may need to adjust the slides on the panel side to get both slides in sync. To do this, loosen the bolts holding the slides to the panel and push the panel toward the cab until both slides are fully locked. Retighten the bolts once everything is properly adjusted. We **HIGHLY RECOMMEND** using blue loctite on these bolts.



**FIG 10**

