



**TACOMA SLIDING
MOLLE PANEL**
MOUNTING INSTRUCTIONS



STEP 1.

Remove factory bed bolt, tie down point and top rail bolt shown in Figure 1

STEP 2.

Step 2. Place the rear bracket shown in Figure 1 and align the three slots on the brackets with the factory bolt holes. Reinstall the factory bed bolt, the top rail bolt, and the 7/16-20 grade 8 bolt supplied with your kit.



FIG 1

IF EQUIPPED WITH FACTORY STORAGE IN BED SIDES.

STEP 1.

Remove the two(2) factory screws closest to the cab on the storage bin shown in figure 2.

STEP 2.

Place the Front bracket (shown in Fig 2)



FIG 2

STEP 3.

Install Slides to brackets using provided countersunk screws and washers. Place screws through the chamfered holes on the slides. You may have to slide the interior mechanism of the sliders out in order to access the chamfered bolt holes and then replace them after you have secured it to the brackets.



FIG 3



STEP 4.

Slide the panel and slide channel into the sliders installed in step 3. Once lined up push all the way in until the panel locks into place.

STEP 5.

There may be some adjusting of the panel forward and backward to fit your truck or preference. Simply loosen the button head screws on the panel, adjust the panel to your liking and retighten.



FIG 4

