



1. Remove Compact Camper from storage bag and lay underneath your Compact Shelter. Locate the door and make sure it is facing your desired direction.



2. Start by hooking the center hooks to the truss bars adjacent to the central peak pole.



3. Continue working around your Compact Shelter hooking the remaining straps to the truss bars. Adjust strap tension to reduce slack.



4. Secure Velcro straps to each of the frame legs.



5. Connect each bottom corner hook into the footplate of the Compact Shelter frame.



6. Your setup is now complete. Enjoy!