



info@calworkssolutions.com

Sig P365 X Macro RMRcc Mount

*****PRODUCT DOES NOT FIT ANY OTHER FIREARM MODEL OR OPTIC*****



Needed for installation

Contents in package:

2x Silver allen head bolts
2x Black allen head bolts
1x Mount

Tools Required:

T25 Torx key or bit
2.5mm Allen key or bit
Driver for bit(if used)
Blue Loctite (if desired)

Other Requirements:

Sig P365 X Macro pistol
Trijicon RMRcc optic



Instructions

1. Clear firearm
2. Remove slide
3. Remove factory sight mount plate bolts with T25 Torx tool. Be careful not to strip them as the factory bolts have blue loctite on them and make them difficult to remove.



4. Remove the cover, clean the threads in the holes if you have the means to do so.



5. Place the CWS RMRcc Mount in place and press it onto the slide firmly until it sits flush on the slide. Note*** It is a tight fit and may take some pressure.



6. Using a 2.5mm allen tool, secure the two supplied silver bolts into the sunken holes on the mount and into the slide. Apply blue loctite if you wish to have a more permanent/secure installation. Snug both

bolts equally to 18 in-lbf(snug).



7. Place the RMRcc seal plate onto the mount.



8. Install battery into RMRcc.



9. Place said RMRcc onto the mount until sitting flush on the mount. Note*** Once again, it is designed to have tight tolerances and will take ample pressure.



10. Using a 2.5mm allen key, install the two supplied black bolts and bolt down the optic. Apply blue loctite if you wish to have a more permanent/secure installation. Snug both bolts equally to 18 in-lbf(snug).



11. Reinstall slide onto the pistol, zero the RMRcc, and ENJOY! Pew, pew... pew pew pew!

