
HARDWARESOURCE HINGE SKU 268402

Salice Silentia Hinge for Face Frame Overlay Cabinets HOW TO CHOOSE THE CORRECT MOUNTING PLATE

sтер 1			our bore distance. Thi und hole drilled into t	s is the distance from the back of the door.	n the edge of the door	r to the edge of	CONV	XIMATE 'ERSION IART
STEP	Ма	asure yo	3mm	1/8"				
2		owing di	4mm	5/32"				
_	the	e product	5mm	3/16"				
	1	Class	the cabinet door.				5.5mm	7/32"
	-	CIUSE I		6mm	1/4"			
	~		a piece of tape vertic	7mm	9/32"			
	2	the fra	ush against the hinged edge of the door. This marks how much the door overlaps frame					5/16"
					9mm	11/32"		
		•	he door until you see	9.5mm	3/8"			
	3		n the inside edge of the tape to the opening of the cabinet door. This is your overlay rension.					13/32"
		annone		11mm	7/16"			
STEP	On	ce you k	e chart below to	12mm	15/32"			
3		termine v	13mm	1/2"				
	of the range	13.5mm	17/32"					
		own. This	14mm	9/16"				
			ou have the op- vould be the 4mm	15mm	19/32"			
		te becau	16mm	5/8"				
	17mm	11/16"						
	18mm	23/32"						
			Змм	BORE DIST/ 4MM	5мм	бмм	19mm	3/4"
							20mm	25/32"

		Змм	4мм	5мм	6мм
	12.5мм то 18.5мм	4mm Plate (SKU 268707)			
	13.5мм то 19.5мм		4mm Plate (SKU 268707)		
OVERLAY RANGE	14.5мм то 20.5мм			4mm Plate (SKU 268707)	
	15.5мм то 21.5мм	1mm Plate (SKU 268706)			4mm Plate (SKU 268707)
	16.5мм то 22.5мм		1mm Plate (SKU 268706)		
	17.5мм то 23.5мм			1mm Plate (SKU 268706)	
	18.5мм то 24.5мм				1mm Plate (SKU 268706)



Hardware Source