## Blum Straight Arm "110 Plus" Hinge for Face Frame Overlay Cabinets HOW TO CHOOSE THE CORRECT MOUNTING PLATE

step <b>1</b>		<b>Measure your bore distance.</b> This is the distance from the edge of the door to the edge of the large round hole drilled into the back of the door.							CONV	APPOXIMATE CONVERSION CHART	
	STEP	<b>Measure your door overlay.</b> The overlay is how much the door overlaps the cabinet. The following directions will tell you how to measure it. For further clarification, there is a link on the product page with more detailed instructions.							3mm	1/8"	
	2								4mm	5/32"	
									5mm	3/16"	
		1 Close the cabinet door.							5.5mm	7/32"	
		1						6mm	1/4"		
		~	Apply a piece of tape vertically to the hinged side of the cabinet so the edge of the tape						7mm	9/32"	
	2 is flush against the hinged edge of the door. This marks how much the door overla the frame.						or overlaps	8mm	5/16"		
									9mm	11/32"	
	<ul> <li>Open the door until you see the edge of the tape between the door and cabinet. Measure from the inside edge of the tape to the opening of the cabinet door. This is your overlay dimension.</li> <li>STEP</li> <li>Once you know the bore distance and overlay of your door, you can use the chart below to</li> </ul>							9.5mm	3/8"		
							your overlay	10mm	13/32"		
								11mm	7/16"		
							art below to	12mm	15/32"		
	3	det	termine v	which mounting p	plate you need. If you find that the chart gives you two mounting			wo mounting	13mm	1/2"	
	<ul> <li>plate options, choose the plate where your overlay is closest to the middle of the range shown. This will give you the largest range of adjustment.</li> <li>Example: if your overlay is 18mm and your bore distance is 6mm, then you have the option of choosing either the 3mm plate or the 0mm plate. While either will work, the best choice would be the 0mm plate because it provides slightly more room for adjustment.</li> </ul>						he range	13.5mm	17/32"		
								14mm	9/16"		
								15mm	19/32"		
								16mm	5/8"		
									17mm	11/16"	
	BORE DISTANCE								18mm	23/32"	
				Змм	4мм	5мм	6мм	7мм	19mm	3/4"	
				6mm Plate					20mm	25/32"	
	8мм то 12мм		(SKU 652306)					20.5mm	13/16"		
	9мм то 13мм 10мм то 14мм				6mm Plate				21mm	27/32"	
					(SKU 652306)	6mm Plate			22mm	7/8"	
						(SKU 652306)			23mm	29/32"	
	11мм то 15мм			3mm Plate			6mm Plate		24mm	15/16"	
В			(SKU 652305)	3mm Plate		(SKU 652306)	6mm Plate	25.4mm	1"		
AN	12мм то 16мм 13мм то 17мм				(SKU 652305)			(SKU 652306)	26mm	1–1/32"	
×R						3mm Plate			27mm	1–1/16"	

14мм то 18мм

15мм то 19мм

16мм то 20мм

17мм то 21мм

18мм то 22мм

**Omm Plate** 

(SKU 652304)

**Omm Plate** 

(SKU 652304)



(SKU 652305)

**Omm Plate** 

(SKU 652304)

3mm Plate

(SKU 652305)

**Omm Plate** 

(SKU 652304)

3mm Plate

(SKU 652305)

Omm Plate

(SKU 652304)

28mm

29mm

30mm

31mm

32mm

33mm

34mm

35mm

1-3/32"

1-1/18"

1-3/16"

1-7/32"

1–1/4"

1-5/16"

1-11/32"

1-3/8"