



office furniture. reimaged.

Steelcase Amia Install Instructions



Components

You will receive a fully assembled chair frame, 5-star base, and a pneumatic cylinder.

Unwrap your components and they should look like the pictures below.



Step 1

Grab the pneumatic cylinder and 5-star base.



Proceed to place the cylinder into the center of the base, pin side up. See below.



Step 2

Take the seat and place it on to the cylinder. Make sure the seat slides into the cylinder.



You may need to apply pressure to make sure it is secured, see below.



Questions?



866.920.8656



furniture@rework-furniture.com



Like What We Do? Give Us a Review!



rework

office furniture. reimaged.