



office furniture. reimaged.

Herman Miller Mirra Install Instructions





Tools

A wrench or power wrench and a 13MM wrench socket.

Components

You will receive a chair back frame, preassembled 5-star base frame, chair back frame cover, and qty 2 screws.

Unwrap your components and they should look like the pictures below.



Step 1

Grab the chair back frame.



Proceed to place the frame on to the center of the chair base, see below.



Grab the qty 2 screws and wrench. Proceed to secure the back and chair base, see below.



Step 2

Once you have secured the qty 2 screws, grab the chair back cover.



Proceed to place the cover, see below.



Questions?



866.920.8656



furniture@rework-furniture.com



Like What We Do? Give Us a Review!



rework
office furniture. reimaged.